

















# OTOMO APARTMENTS INSTRUCTIONS

The elevator shaft is designed to be removeable. Don't glue the roof in place if you want to access the elevator



