













DUCKHUNT ASSEMBLY INSTRUCTIONS







DUCKHUNT ASSEMBLY INSTRUCTIONS



DUCKHUNT ASSEMBLY INSTRUCTIONS



DUCKHUNT ASSEMBLY INSTRUCTIONS



Don't glue the roof in place. You want it to be removable for interior access

DUCKHUNT ASSEMBLY INSTRUCTIONS

